# Large Tote for 22"x27" Panel + 6 smaller panels

Finished tote size: 19" deep by 21" with 3.5" box bottom Includes 2 small outside pockets and 2 inside pockets.

Hint: The remaining 2 small panels could be used to make coordinating zip pouches.





Tote pictured with Desert Bird's "Acequia Parade" panel set.

Materials: Desert Bird panel set that features 1 large 22" x 27" panel and 6 smaller.

- · Canvas: 1 yard of 45" wide canvas.
- Lining: You will need 2 22.5" x 20.5" this should be possible from 3/4 yard of a coordinating fabric that is 42"-45" wide.
- Bag straps: nylon webbing or made from canvas straps
- Optional: 24" x 30" cotton batting
- · Optional: 8" x 22" heavy weight fusible interfacing

#### **Canvas Cut Instructions:**

- Cut 6 canvas bands at 4" x 22.5". These are the top and bottom bands for the outside of the bag and the top band of the lining.
- Cut 1 22.5 x 20.5 panel for the bag back.
- Save the scraps for pocket linings, matching zip bags and handles.

#### **Lining Cut Instructions:**

Cut 2 panels from you bag lining fabric at 22.5" x 20.5" high.

#### Prepare the Pockets - use a 1/4" seam allowance for pockets.

- Select 4 of the smaller illustrated panels for pockets (two will be located on the outside of the bag and 2 on the inside).
- Cut 4 pocket linings to match from any scrap fabric you like.
- Sew each pocket illustration to the lining, wrong sides together, leaving a large gap along the top of the illustration for turning.
- Turn pockets right side out and press. Aim for crisp corners and press the gap edges inside for a straight line.
- Top stitch across top edge to close gap.

### Prepare Bag Front: 1/2" seam allowance

- Optional step: Baste or clip large panel to a piece of cotton batting and machine quilt the panel as desired.
- Trim the top panel to 22.5" wide x 17.5" high. (Yes, you will be cutting off a little bit of artwork on the edges but I tried making a bag with the full panel size and it turned out way too big.). If you did the optional quilting, above, stitch around the perimeter of the trimmed panel 1/4" from the edge to make sure everything holds together.
- Add a 22.5" x 4" canvas band to the top of the panel with 1/2" seam allowance. Press seam towards band and top stitch seam. Repeat for the bottom band.
- Cut a 2" x 2" notch in each bottom corner for the box bottom.

## Prepare Bag Back: 1/2" seam allowance

- Add a 22.5" x 4" band to the top of the 22.5" x 17.5" canvas panel. Press seam toward band and top stitch. Repeat for bottom band.
- Cut a 2" x 2" notch in each bottom corner for the box bottom.
- Center 2 pockets, side by side, on the outside of the bag back. Top stitch around each pocket (sides and bottom) to affix the pockets to the back of the bag.

## Assembly the Bag (outside): 1/2" seam allowance

- With right sides together, stitch the bag front to the bag back along the bottom between the notches using 1/2" seam allowance. Press the seam open.
- With right sides together, stitch the side seams from top to notch using a 1/2" seam allowance. Press seams open.
- Sew the box seams: for each bottom corner, match the bottom seam center to the side seam center. With a little bit of pinching the fabric wings on each side should flatten out to a straight line. Sew across this straight line with 1/2" seam allowance.
- Turn the back right side out and press the top under 1/2".

## Prepare Bag Lining: 1/2" seam allowance

- Add a 22.5" x 4" band to the top of each of the t22.5" x 20.5" lining panels. Press seam allowances toward the band and top stitch.
- Center a pocket on each panel and stitch around pockets (side and bottom) to affix.
- Cut a 2"x2" notch in each lining bottom corner.
- Repeat the outside assembly instructions: sew the bottom seam and press, sew the side seams and press, then sew the bottom box seams.
- Leave the lining inside out but press the top band edge under 1/2"

#### **Final Assembly:**

- Drop the lining inside the bag, matching the side seams. Clip or pin the folded top edges of the bag and lining together. Top stitch to close the seam.
- Add bag handles.